

Portable Identification Label Printer

Brother RJ3150 Mobile Printer

The RJ-3150 printer is Brothers most rugged and fastest Mobile printer, printing at 127mm/sec. Printing 80mm wide labels at 203dpi resolution. (max size of printing area is 72mm on an 80mm label)
Designed with a tough construction, it comes with a certified IP Plastic Rating of IP54 and has drop protection of 1.8m ensuring use under rugged conditions.

The RJ-3150 mobile printer supports ZPL II emulation and utilises direct thermal printing technology, which provides several benefits including higher reliability while reducing maintenance cost with fewer moving parts and requires no replacement toner or ink.

The RJ-3150 is available with Blue tooth and Wi-Fi mobile connection interface

The RJ-3150 printer is ideal for printing barcoded or non-barcoded identification labels for a variety of hospital patient applications including:-

- **Kitchens**
- **EBM**
- **Pathology Specimens**
- **Blood collection**
- **Medication**
- **COWS**
- **Asset Control**



Ask us about solutions packages with matching label consumables and barcode scanner readers tailored for your specialisations

Package includes: Printer, Shoulder Strap, Belt Clip and Li-Ion Battery.	
Printing	
Print Resolution	203 x 200 dpi
Print Technology	Direct Thermal
Print Speed	Maximum 127mm / Second*
Paper Feed method	Roll Feed
Maximum Print Width	72mm
Maximum Print length	1 meter
Drop Protection	1.8meters
Roll width (Max/Min)	80mm / 25mm
Maximum Roll diameter	66mm
General	
Dimension (W x H x L)	118mm x 82mm x 189mm
Weight	670 grams
Battery	Rechargeable Li-Ion Battery
Interface	
USB	Standard
Bluetooth (Ver2.0 + EDR)	Standard
Wi-Fi (802.11 b/g/n)	Standard
AirPrint	Yes
Software Support	
Windows OS driver supported, Android 2.3 or Later, IOS 5 or later	
Supported Commands: P-Touch Template 2.0, Raster , ESC/P	
Emulation Compatibility: ZPL II / CPCL	
Memory	
Ram: 32MB	Flash: 32MB
Sealing Certificate	IP54

